

Fitting instruction Superbike-Kit

Part no.: 120M013

Model: Moto Guzzi V 11 Sport	Year: '00-
Type :	

Important: If you are not a trained motorcycle mechanic stop now. Ask a local motorcycle shop to do the work for you. Please read the LSL-Superbike-Kit Fitting instructions.

Recommended bar:	A01 / L01	
Length of brake-lines:	Original	
Code for cable routing:	Position of cable from riders position ...	
... in front of the fork F	... right from steering head R	
... behind the fork B	... left from steering head L	
Throttle cable:	B / R	
Clutch cable:	B / L	
Choke cable:	B / L	

Drilling of the top yoke is a job to be done only by a trained person on a professional machine.

Instructions:

The top yoke is designed to carry bar clamps as for classic models. To mount the bar clamps you have to bore the necessary 10mm holes into the top yoke. Therefore the kit contains a template to meet the correct points for drilling.

The template has to be fixed by 2 M6-screws on the bottom side of the yoke. The necessary size of driller is 10.0mm. Take care that the top yoke is fixed well and the drilling is produced rectangular.

Further details for the mounting of the clamps and handlebar you find under the "General advices".